

Quick Start Reference Guide

- Upon receipt of the CleanStation, inspect the unit for obvious defects that may have occurred during shipping. Report any damage to the carrier and PM Technologies immediately.
- Place the machine on a solid level surface that will have access to the rear of the machine.
- Close the “FILL VALVE” (closed when handle is parallel to the “OFF” line).
- Install the water supply hoses as labeled. If only cold is available connect it to the hot input on the machine.
- Install the drain hose (1” hose).
- Open the “FILL VALVE” (open when handle is parallel to the “ON” line).
- Fill tank to 1 inch from the top with water. (To extend to life of the machine it is highly recommended to **use conditioned water**).
- Supply 240vac power to the machine.
- Insure “CONTROL VALVE” arrow is pointing to “CLEAN PARTS”.
- Turn selector switch to “CLEAN PARTS”.
- When control displays **0000** press the down arrow key.
- Put one and a half bottles of WaterWorks Soluble Concentrate into the water, when the machine is running and the water is heated up to 150 degrees.
- Place parts directly into the tank, or if purchased into the basket which goes into the tank.
- The default time and temp is 4 hours, 150 degrees.

